

# Disassembly Instructions

Midway seating comes in one, two, and three seaters and can be specified as freestanding or connected, arms of wood or polyurethane, spacer, radius and corner tables, and bariatric. Two and three seaters offer a choice of no arms, half arms or full arms to the floor. Corner or spacer tables in plastic laminate top, self-edge or PVC edges are available to create any size and shape for your configuration.

Recyclable Material (lbs) 	
steel frame	18.91
wood armrest	1.68
Total Weight	
	21.90

\*values based on Midway single seater.



single seater

midway

Tools: Phillips head or Robertson screwdriver, box cutter knife, hammer or rubber mallet, pliers.

Skill Set: Good manual dexterity.

Estimated Time: 19min

## Steps:

### 1. Seat - 4min

To begin disassembly, flip the chair upside down in order to access the under side of the seat. Locate the four fasteners and unfasten. Return the chair to its upright position and remove seat component from frame and place to the side.

### 2. Glides - 4min

With a flat head screwdriver or similar tool, pry foot glides free from legs. This may require the assistance of a hammer or rubber mallet. Repeat process to all four feet.

### 3. Back - 4min



With the chair now in its upright position, locate the velcro upholstery strip at the base of the back rest. Open the velcro upholstery strip the entire length of the back (see illustration). Remove upholstery back cover by slipping upward off the chair frame (if upholstery is too difficult to remove, carefully make a long incision down the center of back and remove). \*In some cases there is a fire barrier between the upholstery cover and mesh layer. In this event, simple cut away with caution.



removing tape).

At the base of the back, same position as velcro strip, divide the internal back mesh from velcro tape. Remove mesh with the same techniques used as upholstery cover. Remove adhering tape from the chair frame and discard (a sharp object may be required in order to start

In the event of disassembling a Midway bariatric seat and some custom orders, internal support strapping may be present. To remove, simply unhook from the holes.

### 4. Armrest - 2min

Locate the three fasteners on the underside of the armrests. Unfasten and remove armrests from frame.

### 5. Upholstered components. - 5min

Seat - Open velcro strap and unzip the zipper to remove upholstery. If a fire proof liner is present under the upholstery cover, carefully cut away and separate from foam.

Visit spec's green news page at [specfurniture.com](http://specfurniture.com) and click on "End of Product Life Options" for recycling and biodegradation facilities.

## Family



single mesh



single highback



hip chair



ottoman

# Disassembly Instructions Accessories



## Armrest

Two options of both wood or polyurethane armrests are available. The disassembly procedure will be the same for both products as seen on pg.1 of the Midway disassembly instructions. Recycling options are available for wood options only. Visit [specfurniture.com](http://specfurniture.com) for more information.



## Ottoman

To disassemble the Ottoman, locate the fasteners on the underside and unfasten. Remove upholstery cover using the technique used in step 5 - Upholstered Seating Components, in the Midway disassembly instructions.



## Connection components

If any connecting hardware is present, remove at the beginning of the disassembly. Locate the fasteners at either end of the connecting bars . Unscrew fasteners and dislodge connecting bar from surrounding chair frame. If a table sectional is present, once again locate fastening screws on underside and unfasten. Remove table surface from connecting frame.

midway