

Disassembly Instructions

In the Gravity line, one, two and three seaters are available, freestanding or connected, with a bariatric option. Spacer tables, end tables and corner tables are used to create configurations of any size and shape. For all seats and configurations, the disassembly process will be the same. Arms are offered in steel, poly and wood.

Recyclable Material (lbs)



steel frame	18.90
wood armrest (qty. 2)	1.68

Total Weight	20.58
--------------	-------

*values based on a standard Gravity



single seater

Tools: Phillips head or Robertson screwdriver, Hex key set, box cutter knife, pliers and flat head screwdriver or similar tool.

Skill Set: Good manual dexterity.

Estimated Time: 15min per chair.

Steps:

1. Back - 4min

To begin, find the velcro opening at the base of the back and open. Roll the upholstery cover up from the bottom to about half way or until foam flap is fully revealed. Lift the flap to reveal the steel fastening plate. Locate the 3 fasteners and unfasten with the required 1/4" hex key. Once unfastened lift the back vertically to remove from frame. Place the back to the side for future instructions.

2. Seat - 2min

Turn the chair upside down to access the underside of the seat. Locate the four fasteners located on the underside of the chair frame and unfasten with the required Hex key. Remove the seat from the chair frame and place to the side for future instructions.

3. Glides - 4min

Once both the seat and back are removed from the frame, re-position the chair upside down to access the feet glides. With a flat head screwdriver or similar tool, wiggle the flat surface between the glide and steel frame. Begin to pry the glide out of the frame. Repeat process for all four feet. In addition to the feet glides, there are four similar plastic caps present at the end of the support bars on the underside of the seat.

4. Armrest - 2min (IF APPLICABLE)

To continue the disassembly, locate the three fastening points on the underside of each arm. These point are indicated by a back plug. As instructed in step 3, pry the plugs from the frame with a flat head screwdriver or similar tool. Removing these plugs will reveal the fasteners.

Remove the screws with the required screwdriver and detach armrest from frame. Repeat process to all armrests. Recycling options are only available for the wood arm.

5. Upholstered components. - 5min

Back - Remove upholstery from the back by continuing to roll the upholstery upward off the back.

Seat - Locate the zipper and velcro opening on the underside of the seat. Unzip the zipper and open the velcro opening. By starting from the front of the seat (velcro end), pull back the upholstery cover and remove.

Visit spec's green news page at specfurniture.com and click on "End of Product Life Options" for recycling and biodegradation facilities near you.



two seater



three seater

GRAVITY