

# JAZZY

## Disassembly Instructions

### Recyclable Materials (lbs) ♻️

Metal	9 - 13 lbs
Wood / Laminate*	6 - 7 lbs
Plastic	0.2 lbs

### Total Weight 17 - 20 lbs

\*All wood or wood and laminate shells available

People: 1

Tools: drill / screwdriver, #2 Phillips bit, gripping gloves

Skill Set: good manual dexterity

Estimated Time: 4 mins per Jazzy chair

1. Remove Wood Screws: 2 mins

Using a drill or screwdriver, remove the 16 wood screws located underneath the seat.

2. Remove Clips: 1 min

Disassemble the parts; lift the frame off of the shell and take the 4 attachment clips off of the frame.

3. Remove Glides: 1 min

Using gripping gloves, remove the 4 glides from the chair frame by popping them off with force.



**Spec Furniture Inc.**

Tel: 416.246.5550 Fax: 416.246.5549 Toll Free: 1.888.761.7732

specit@specfurniture.com [www.specfurniture.com](http://www.specfurniture.com)

**spec**™