





TAILOR MODULAR

Seat to Seat Connection


NOTE: Straight arms will be connected to another seat or table.




NOTE: Tapered arms are on the outside and do not connect to another seat or table.




CONNECTION WITHOR WITHOUT ARMS.



STL-0561
Connecting Plate
x1




HDW-0067
5/16" Split Lock Washer
x2



HDW-0056
5/16" - 18 x 1"
Socket Head Cap Screw
x2

NOTE: QUANTITIES ARE PER CONNECTION.


CONNECTION WITH 1" SPACING BETWEEN ARM AND SEAT.



STL-0636
Connecting Plate
x2



HDW-0067
5/16" Split Lock Washer
x4






HDW-0056
5/16" - 18 x 1 3/4"
Socket Head Cap Screw
x4

NOTE: QUANTITIES ARE PER CONNECTION.

1A



OPTION WITHOUT 1" SPACING (IF SPACING PROCEED TO NEXT STEP 1B)





PROCEED TO STEP 2

1B


OPTION WITH 1" SPACING



Flip seat over and remove four bolts shown.





2






3




WITHOUT CENTRE ARM



WITH CENTRE ARM



WITH 1" SPACING BETWEEN ARMS AND SEAT



Spec Furniture Inc.

165 City View Drive, Toronto ON, M9W 5B1

P: 416.246.5540 | **F:** 416.246.5547

E: specit@specfurniture.com | specfurniture.com