




TRAFFIC


7000 Series

Connected Seating and Tables


INS-0008 R7 06-01-2017








FOOT ASSEMBLIES










*PER LEG

BEAM SLEEVES










*PER CONNECTION

BEAM END CAP



END ARM ASSEMBLIES
















*PER ARM

SHARED ARM ASSEMBLIES















*PER ARM

SEAT ASSEMBLIES





HDW-0066
5/16-18 x 3/4" Bolt

x4




HDW-0067
5/16" Lock Washer


x4

*PER SEAT

CORNER TABLE ASSEMBLIES



FRM-0552
12" Bracket



x2



HDW-0094
1/4-20 x 3/4" Carriage Bolt

x4



HDW-0028
#12 X 7/8" Wood Screw

x8




HDW-0068
1/4-20 Nylon Lock Nut


x4

*PER CORNER TABLE

CORNER TABLE ASSEMBLIES







GLD-0004
Glide

x4



HDW-0068
1/4-20 Nylon Lock Nut

x2



HDW-0094
1/4-20 x 3/4" Carriage Bolt

x2



HDW-0031
1/4" Lock Washer

x1





HDW-0031
1/4" Lock Washer

x1

*PER CORNER TABLE


SPACER TABLE ASSEMBLIES





FRM-0553
Left Spacer Table Bracket

x1



FRM-0554
Right Spacer Table Bracket

x1



HDW-0094
1/4-20 x 3/4" Carriage Bolt

x4



HDW-0028
#12 X 7/8" Wood Screw

x4




HDW-0068
1/4-20 Nylon Lock Nut

x4

*PER SPACER TABLE

SPACER TABLE ASSEMBLIES





HDW-0094
1/4-20 x 3/4" Carriage Bolt

x4




HDW-0068
1/4-20 Nylon Lock Nut


x4


*PER SPACER TABLE

FOOT ASSEMBLIES


1









2







BEAM SLEEVES ASSEMBLIES

3







TIGHT!



END ARM ASSEMBLIES


4








SHARED ARM ASSEMBLIES


5













SEAT ASSEMBLIES


6





*__NOTE__: EITHER REAR OR FRONT HOLES CAN BE USED TO MOUNT SEATS. USE FRONT SET OF HOLES FOR WALL SAVING OR WHEN SEATS ARE BACK TO BACK.

7













LAMINATE CORNER TABLE ASSEMBLIES


8














9




10



11




12




METAL CORNER TABLE ASSEMBLIES


13



14





15





LAMINATE SPACER TABLE ASSEMBLIES


16













17










*per table


METAL SPACER TABLE ASSEMBLIES


18













PLASTIC END CAPS

19





Spec Furniture
165 City View Drive, Toronto ON, M9W 5B1
P: 416.246.5540 | F: 416.246.5547
E: specit@specfurniture.com | specfurniture.com