







TAILGATE


Media Wall Assembly




#3




OPTIONAL TV WALLMOUNT




x1



x1



x1



x1

HDW-0028
#12 x 7/8" Wood Screw



x8

HDW-0029
#8 x 3/4" Tapping Screw



x6

HDW-0654
6-32 x 1/2" Machine Screw




x4

HDW-0653
6-32 Rectangle Nut




x4

GLD-0004
5/16-18 x 3/4" Leveller



x2


HDW-0660
Levelling Glide Bracket



x2



Skip to STEP 2 if TV Wallmount option was not selected.

1







POSITION TV WALLMOUNT IN
DESIRED PLACE AND FASTEN
TO MEDIA WALL.


2




3








4



5



6



Spec Furniture Inc.

165 City View Drive, Toronto ON, M9W 5B1

P: 416.246.5540 | **F:** 416.246.5547

E: specit@specfurniture.com | specfurniture.com