




## HARDI ENDURANCE OPEN CHEST FLOOR MOUNTING INSTRUCTIONS




You will need:




**1x**

Pencil  
For Marking Floor




**1x**

Drill  
With 3/8 Bit



**4x**

3/8-16 x 3.75"  
Security Torx Anchor Bolts



**4x**

Flat Washer

- 1.** Position open chest on its top as to access the bottom of the open chest.
- 2.** Select and drill all four mounting locations on the bottom of the open chest.
- 3.** Place open chest right side up and locate where it is to be secured to the floor.
- 4.** Using a pen or pencil, mark mounting hole locations on the floor using the holes drilled in step 2.
- 5.** Move open chest and drill holes in the four locations where you marked the floor. Hole depth should be 2.0" deep MINIMUM.
- 6.** Replace the open chest lining up the drilled holes with the holes in the floor.
- 7.** Place one flat washer over each of the four anchor bolt and guide the bolts through the open chest and into the holes into the floor.
- 8.** Tighten each anchor bolt 3-5 turns past finger tight.