

Urban

Disassembly Instructions

There are 3 versions of the Urban chair. Plastic seat and back, upholstered seat and back or upholstered seat with a plastic back.

Recyclable Material (lbs)

Steel	8.58
Plastic	9.06

Total Weight 17.64



Tools: Phillips head or Robertson screwdriver, Flathead screw driver, box cutter knife, hammer or rubber mallet, pliers.

Skill Set: Good manual dexterity.

Estimated Time: 10-15 min per chair.

Steps:

1. Plastic Back - 4min

Remove the screws from the bottom of the back. Slide the back plastic cover up and off. Remove the screws hold the back to the steel frame. The back is now free. There is a small strip of plastic that the back cover clipped onto. You can remove this piece as well by removing the screws.

Upholstered back

Once the back cover is removed, remove the back from the frame. Flip the back upside down and use a flathead screwdriver to pry the fabric out of the groove on the underside of the back. The fabric sleeve can now be pulled up and off. The foam has been glued on and can be ripped away from the plastic.

2. Plastic Seat - 2min

Turn the chair upside down to access the underside of the seat. Remove the fasteners located on the underside of the seat pan. Remove the seat panel from the chair frame. The seat consists of 2 parts. The bottom piece is entirely made out of recycled plastics (all 7 types). The top is made of the same type of plastic with a polyurethane foam molded over it. Both pieces can be recycled where similar plastics are made.

Upholstered Seat

Once the four screws have been removed, the seat separates into 2 pieces. The bottom piece is entirely made out of recycled plastics (all 7 types). The top is an upholstered piece of the same type of plastic. Pry off the staples with the flathead screwdriver and remove the fabric and foam.

3. Feet Glides - 1min

Once both the seat and back are removed from the frame, re-position the chair upside down to access glides. With pliers, firmly grasp the glide and wiggle upward until free. Repeat process for all four feet.

4. Arms - 2min

Place the chair frame on its side. Put one foot on one of the legs on the ground and with a rubber mallet or hammer, knock the underside of the arm rest. Continue to knock until the armrest is free from the frame. This process may require some force. Flip the chair to the opposing side and repeat the process. This plastic is not recyclable.

You are now left with the steel frame which is recyclable.

Visit Spec's green news page at specfurniture.com and click on "End of Product Life Options" for recycling and biodegradation facilities near you.

